

Updating the software: instructions

In order to update the software with both the latest functions and settings while retaining your current personal settings: Follow all the steps in these instructions.

If you do not have any personal settings that must be retained, you can skip over the steps specified for that purpose.


1. Save the unzipped files in the root directory of a USB flash drive.

2. To retain personal settings:

Only for air curtains with version one (UI.x-xx)

Not all personal settings are automatically copied.

From the current software version, note down the following settings from the *b-touch* control panel:



Door response		
menu > Configuration > 25. Auto: Door response		
	Door response	□ / ◡
	Fan speed	auto / ... %
	Room temperature control	on / off
	Fan speed for room temperature control	... %
	Stand-by heating	auto / ... %
Door contact switch		
menu > Maintenance > Status		
	i3 (input 3)	No function / Door contact switch (NO/NC)


3. To retain personal settings:

Export the existing settings:

- Connect the USB flash drive to the control panel.
- Select [Export Settings](#).

4. Install the new software version:

- Select [Update control panel](#) in order to update the software of the control panel.
- Select [Update unit](#) in order to update the software of the unit.



**Note:**

In a few cases, an error message may (repeatedly) appear. Abort the update and try again until the update is entirely completed.

- When the installation has been completed, disconnect the USB flash drive.
- The unit will carry out a restart. This may take a while. Wait until the control panel has sought and found the connected units again.
- Check in the status screen to see whether the software versions have been updated:
[menu > Maintenance > Status](#).

5. Restore the factory configuration:

[menu > Maintenance > Factory configuration](#).

**Note:**

If the installation guide () starts up, you can abort this by pressing on **X**.

6. To retain personal settings:

Import the existing saved settings:

- Connect the USB flash drive to the control panel again.
- Keep the function [Import settings](#) pressed down **until** the progress of the process and the file name 'settings_export.txt' are displayed.

**Caution:**

If the file name **is not** displayed, you have not pressed on the function for long enough. Press on it again **until** the progress and the file name are displayed.

**Note:**

Ignore any warning about unknown parameters.

7. Import the file 'settings.txt':

- Press on the function [Import settings](#) **briefly**.

**Caution:**

If the file name 'settings_export.txt' is displayed during the progress of the process, you have pressed on the function for too long. Press on it again **briefly** until the progress is displayed without a file name.

- When the importation has been completed, disconnect the USB flash drive.

8. To retain personal settings:

Only for air curtains with version one (UI.x-xx)

Check whether the settings noted down in step 2 are still set properly, and adjust them if necessary:

- Settings for door response: [menu > Configuration > 25. Auto: Door response](#).
- Settings for door contact switch:
If [Status i3](#) was set to 'Door contact switch' (NO/NC):
Check the operation of the door contact switch via
[menu > Maintenance > Check door contact switch](#).

9. Reset the system: [menu > Maintenance > Reset system](#).**10. Possibly, check whether new functions have been added to the control panel for which you wish to use a setting different from the default value.**